

## SEA-BIRD ELECTRONICS, INC.

1808 136th Place N.E., Bellevue, Washington 98005 USA Telephone: (425) 643-9866 Telex: 292915 SBEI UR

Fax: (425) 643-9954 email: seabird@seabird.com

SBE P/N 50062

DATE	REV	REVISION RECORD	AUTH	DR	CHK
02.99	Α	Add Drawing, reformat document	MJ	CEG	
07.13.04	В	Changed Descriptions for Impeller and Pump Head o-rings	ET	KLP	
03.17.06	С	Add Thrust Washer, PN 30095	CB	MJ	
06.04.07	D	ECN 1096: Universal external PC pump housing O-ring kit		PC	

## SBE 5M / 5P / 5T Pump Housing O-Ring Kit

#### KIT CONTENTS

SBE P/N	Manufacturer P/N	Primary SBE Application	QTY
30010	Pump Thrust Washer, 115-033-10	Thrust Washer for Pump Impeller	2
30082	Parker O-Ring, 2-213 N674-70	Connector Endcap O-Ring for 5T	1
30095	Parker O-Ring, 2-002 N674-70	Pump Impeller O-Ring	1
30571	Parker O-Ring, 2-124 N674-70	Pump Head O-Ring	1
31011	Parker O-Ring, 2-026 N674-70	Impeller Endcap O-Ring for 5M / 5P	1

# Pump Housing O-Ring Replacement

### A. General O-Ring Installation

- 1. O-rings must be cleaned and lubricated with Silicone-Based lubricant before installing.
- 2. Never use petroleum-based lubricant.
- 3. Never clean an o-ring with any type of abrasive material.
- 4. Always inspect all o-rings and o-ring surfaces for scratches or dirt before installation.

### **B. Pump Impeller O-Ring and Thrust Washer** (30095, 30010)

- 1. Install one of the thrust washers (30010) onto the shaft.
- 2. The Impeller should then be slid down all the way onto the shaft, followed by the second thrust washer (30010).
- 3. Secure the fixture into placed with the pump impeller o-ring (30095).
  - a. Do not put any lubricate on this o-ring.

#### **C. Pump Head O-Ring** (30571)

- 1. Lube the o-ring groove (on housing for 5T, on impeller endcap for 5M/5P) and Pump Head O-Ring (30571).
- 2. Install the o-ring into the o-ring groove.
- 3. Press the o-ring as tightly as possible into the groove.
- 4. Backthread the pump head (23593) over the O-Ring until both are firmly seated and then thread the pump head hand tight onto the housing.

### **D. Connector Endcap O-Ring** (30082)

- 1. Lubricate the o-ring and o-ring groove, as well as the housing seating surface with o-ring lubricant.
- 2. Install the o-ring by carefully sliding it completely over the bulkhead connector.
- 3. Next, use a plastic spatula to pry the o-ring over the endcap into its groove.

<u>SBE DRAWING:</u> <b>67029.02</b>	Sea-Bird Electronics Procedure		
	PROCEDURE NUMBER: 67029		
TITLE: 5M/5P/5T Pump Housing O-Ring Kit	TITLE: SBE 5M/5P/5T Pump Housing O-Ring Kit		
	REVISION: <b>D</b>		
	EFFECTIVE DATE: <b>03/17/2006</b>		
	CHECKED BY: Page 1 of 2		



## SEA-BIRD ELECTRONICS, INC.

1808 136th Place N.E., Bellevue, Washington 98005 USÁ Telephone: (425) 643-9866 Telex: 292915 SBEI UR Fax: (425) 643-9954 email: seabird@seabird.com

### E. Impeller Endcap O-Ring (31011)

- 1. Lubricate the o-ring and o-ring groove, as well as the housing seating surface with o-ring lubricant.
- 2. Install the o-ring into the o-ring groove furthest from the impeller side of the endcap.

<u>SBE DRAWING:</u> **67029.02** 

TITLE: 5M/5P/5T Pump Housing O-Ring Kit

**Sea-Bird Electronics Procedure** 

PROCEDURE NUMBER: 67029

TITLE: SBE 5M/5P/5T Pump Housing O-Ring Kit

REVISION: **D** 

**EFFECTIVE DATE: 03/17/2006** 

CHECKED BY: \_\_\_\_\_ Page 2 of 2

