

SEA-BIRD ELECTRONICS, INC.

1808 136th Place N.E., Bellevue, Washington 98005 USA Telephone: (425) 643-9866 Telex: 292915 SBEI UR Fax: (425) 643-9954 email: seabird@seabird.com

SBE P/N Varies

| DATE | SYM | REVISION RECORD | AUTH | DR | CHK |
|------|-----|-----------------|------|----|-----|
| | | | | | |
| | | | | | |

SBE37SM Welded-Bolt Cable Clamp Kit

Kit Contents

| SBE P/N | Manufacturer P/N | Primary SBE Application | QTY |
|---------|------------------------------------|---|-----|
| 231447 | SBE 37SM Custom Mount Guard | Cable Mount Guard | 1 |
| Varies | Microcat SM Clamp, Diameter varies | Mounts to Upper end of Guard | 2 |
| Varies | Microcat SM Guide, Diameter varies | Mounts to lower end of Guard | 2 |
| 30633 | Washer, Ti, 1/4" Split | Secure 231477 Guide to Custom Mount Guard | 2 |
| 30634 | Washer, Ti, 1/4" Flat | Secure 231477 Guide to Custom Mount Guard | 2 |
| 30835 | Nut, 1/4-20, Hex Ti | Secure 231477 Guide to Custom Mount Guard | 2 |
| 30864 | Washer, Ti, 3/8" Split | Secure 231476 Clamp to Custom Mount Guard | 2 |
| 30910 | Nut, 3/8-16 Ti | Secure 231476 Clamp to Custom Mount Guard | 2 |
| 30911 | Washer, 3/8" Flat Ti | Secure 231476 Clamp to Custom Mount Guard | 2 |

3/8" Cable Diameters

| SBE P/N | Manufacturer P/N | Primary SBE Application | QTY |
|---------|----------------------------|------------------------------|-----|
| 231476 | Microcat SM Clamp, 3/8" OD | Mounts to Upper end of Guard | 2 |
| 231477 | Microcat SM Guide, 3/8" OD | Mounts to lower end of Guard | 2 |

8.5mm Cable Diameters

| SBE P/N | Manufacturer P/N | Primary SBE Application | QTY |
|---------|-----------------------------------|------------------------------|-----|
| 231425 | Microcat SM Clamp, 5/16"/8.5mm OD | Mounts to Upper end of Guard | 2 |
| 231424 | Microcat SM Guide, 5/16"/8.5mm OD | Mounts to lower end of Guard | 2 |

Procedure for Clamp Installation

Refer to Assembly Drawing number67034A

A. Assembly Of Custom SM Cable Mount Guard

- 1. Guard comes with necessary bolts welded onto it.
- 2. Press 1 each of guide and clamp parts firmly over bolts such that blocks are flush with mount guard, and holes face outward.
- 3. Lay cable in holes and slip 2nd clamp and guide parts over cable.
- 4. Secure clamp and guide with 1 each flat split ring washer, and 1 nut as outlined above.

SBE Drawings:

67034A Microcat SM Clamp/Guide Assembly **21489A** Microcat Mount Guard Welding Mod **21425A** Microcat Guard Mod, welded bolts

Sea-Bird Electronics Procedure


PROCEDURE NUMBER: 67034

TITLE: SBE37SM Welded-Bolt Cable Clamps

REVISION: A

EFFECTIVE DATE: 06/14/2006

CHECKED BY: PAGE 1 of 1



Miller Car

