

SEA-BIRD ELECTRONICS, INC.

1808 136th Place N.E., Bellevue, Washington 98005 USA Telephone: (425) 643-9866 Telex: 292915 SBEI UR Fax: (425) 643-9954 email: seabird@seabird.com

				_	
DATE	REV	REVISION RECORD	AUTH	DR	CHK
10.03		Change to Drawing only	CB	KLP	
3.9.04	Α	Changed 30452 to 31263	CB	KLP	

SBE P/N 80403

SBE3 to SBE21 Remote Temperature Mount Kit

Kit Contents

SBE P/N	Manufacturer P/N	Primary SBE Application	QTY
23404	Temp Plenum Retainer	Secures Temp Sensor To Plenum	1
23405 Temp Plenum, Stainless Steel		Provides water flow to temp probe	
23618	SBE 21 Remote Temp Mount Plug	Seals Plenum Retainer opening when not in use	1
30254	Washer, ¼" Split Ring Lock	Use with Plenum Hardware (30451)	2
30451	Bolt, ¹ / ₄ -20 x 2-3/4 HEX SS	Secure Plenum Retainer to Plenum	2
30570	Washer, ¹ / ₄ " Flat SS	Use with Plenum Hardware (30451)	2
30809	Morrison seal, .047" hole, Nit	Fits in between Plenum and Plenum Retainer	1
31263	Pipe, 1" Threaded, SS	Interface Plenum to plumbing system	2

Procedure for Installation

Drawing number 67040


A. Assembling The Plenum

- 1. Lubricate the Morrison seal with a Silicone-based lubricant. Never use a Petroleum-based lubricant on SBE o-rings and seals.
- 2. Clean the Morrison seal surface on the Stainless Steel Plenum (23405) and install the Morrison seal with hole facing out of the plenum.
- 3. Place the Plenum Retainer (23404) so that the small hole rests on top of the Morrison seal.
- 4. Secure the Retainer to the Plenum with two bolts (30451) and washers (30254, 30570). The lock washer should rest between the bolt head and the flat washer.
- 5. Wrap plumber's tape around the threads of the pipes and install them into the plenum as needed to make the assembly fit your present plumbing configurations.

B. Installing The Sensor

- 1. Remove the Temperature Probe Guard from your SBE 3S sensor.
- 2. Insert the temperature probe carefully into the Plenum Retainer and screw it in until flush.
- 3. When the sensor is not in use, replace the probe with the temperature mount plug (23618). Be sure to re-install the probe guard onto the SBE 3S before storing it or putting it to other uses.

Parent Part Number: 80403 / 90387 <u>SBE Drawings:</u> 67040 SBE3S, External Temp Mount Kit Assembly	Sea-Bird Electronics Procedure PROCEDURE NUMBER: 67040 TITLE: SBE21 Remote SBE3 Temperature Kit REVISION: A EFFECTIVE DATE: 03/09/2004
	CHECKED BY: PAGE 1 of 1



DATE	SYM	REVISION RECORD	AUTH.	DR.	CK.
10.10.03	А	added pipe size	СВ	KLP	
3.9.04	В	ADDED QTY		KLP	

TOLERANCES	SEA-I	BIRD E	LECT	RONICS,	INC
FRACTIONAL	P/N 8	0403	SCALE	DRAWN BY APPROVED BY	٨J
		00100			
DECIMAL	TITLE	External Temp Pleni Mount Assembly			
ANGULAR	DATE 01.18.99	DRAWING NU	MBER 6	67040	REVB