

SBE P/N 50479

SEA-BIRD ELECTRONICS, INC.

13431 NE 20th St., Bellevue, Washington 98005 USA Telephone: (425) 643-9866 Fax: (425) 643-9954

Telex: 292915 SBEI UR Email: seabird@seabird.com

	DATE	REV	REVISION RECORD	AUTH	DR	CHK
_						

SBE 37 V3 Through-Bolt Mounting Structure Assembly Kit

KIT CONTENTS

SBE P/N	Manufacturer P/N	Primary SBE Application	QTY
231736	SBE37 Through-Bolt Mount, Part 1	Mount secures to sensor endcap	1
234186	SBE37P Microcat Thru-Bolt Mount Pt 2	Mount secures to connector endcap	1
30633	Washer, 1/4" Split ring lock, Ti	Used with sensor endcap securing bolts	2
30634	Washer, 1/4" Flat, Ti	Used with sensor endcap securing bolts	2
30790	Bolt, 1/4-20 x 3/4 Hex Ti	Secure mount part 1 to sensor endcap	2
31066	Cap Screw, 8-32 x 3/4 Socket Head, Titanium	Secure mount part 2 to connector endcap	3

Installing Through-Bolt Hardware onto a Microcat

A. Install Mount part one into sensor endcap


- 1. If other mounts exist, simply remove these and set them aside.
 - a. You may need to remove the single screw securing lower sensor endcap mount onto the endcap itself.
 - b. You will not be using any parts from these mounts.
- 2. Install mount part 1 (231736) onto sensor endcap, such that sunken holes are facing out from the microcat housing.
- 3. If is recommended to use NeverSeez on all hardware.
- 4. Secure mount part 1 to sensor endcap with 2 bolts (30790), 2 lock washers (30633), and 2 flat washers (30634)
 - a. Install Lock washer first onto bolt, followed by flat washer.
 - b. Cover remaining exposed bolt threads with NeverSeez after installing washers.
- 5. You will be easily able to install your mounting hardware through the remaining (outer) pair of holes on the mount.

B. Install Mount part two into connector endcap

- 1. If current mounting assembly exists, remove this and set it aside. You will not need any parts from this mounting fixture.
- 2. Endcap may be installed in the reverse direction from where you want it. In this case, first install the mount part 2, then use that mount to carefully turn the endcap 180°.
- 3. Install mount part 2 (234186) onto connector endcap, such that screw holes all line up, and counterbores face away from the microcat endcap.
- 4. Secure to endcap with three screws (31066).
- 5. It is recommended to use NeverSeez on all hardware.
- 6. You will be easily able to install your mounting hardware through the remaining (outer) pair of holes on the mount.

SBE DRAWING: 67218	Sea-Bird Electronics Procedure
	PROCEDURE NUMBER: 67218
<u>TITLE:</u> SBE37 V3 Through-Bolt Mounting	TITLE: SBE37 V3 Through-Bolt Mounting Hardware Kit
Assembly	REVISION:
	EFFECTIVE DATE: 10/31/2011
<u>REV:</u>	CHECKED BY: <u>PC</u> PAGE 1 of 1

		8		7	6		
	item NO.	PART NUMBER	DRAWING NUMBER	DESCRIPTION	QTY.		
	1	231736	21850	SBE37 Microcat Thru-bolt Mount Pt1	1		
	2	234186	234186	SBE37P Microcat Mount Pt 2	1		
D	3	30633	N/A	Washer, 1/4" Split Ring Lock, Titanium	2		
	4	30634	N/A	Washer, 1/4" Flat, Titanium	2		
	5	30790	N/A	Bolt, 1/4-20 x 3/4 Hex Hd, Titanium	2		
	6	31066	N/A	Cap Screw, 8-32 X 3/4 Socket Head, Titanium	3		



	3			1	2		I		1			
REV.	DATE	ZONE		1	DES	CRIPTIC)N		AUTH	DWG	СНК	
												D
												С
												_
												В
					DATE		וחוח					
DIME	SS OTHERWISE SPECIFI NSIONS ARE IN INCHES RANCES:		AWN	PC	DATE 02/16/11		3431 NE	20th Street, Belle	VUE, WA	, 5, 11 , 98005	IC.	
FRAC	TIONAL±1/x JLAR: ±0.5° BEND :	+			1	TITLE:		425-643-9866				
.XX	± .05 TYP RAD ± .01 ± .003	.01 DRA SEA	AWING I: A-BIRD EL	S THE SOLE P ECTRONICS,	Roperty of INC. Any			cat V3 Thru-Bolt I	Vicroca	at Struc	ture	A
MACI	HINED SURFACES	WITI SEA	HOUT TH	IE WRITTEN PI	or as a whole Ermission of Inc. Is prohibited.	PART	NO.	504	79			
PER: Al	RET GEOMETRIC TOLERAN NSI Y14.5M - 1994		MMENT	S:	JD BREAK	SIZE	DWG.		, /			
MATER FINISH				SHARP ED	GES	B		672 [°]	18			
	N/A NOT SCALE DRAWING	_	VICI Pa J/A	art/Drav /	w Info N/A		E: 1:2			EET 1 (OF 2	
	3	1	-	1	2			1	1			


С

В

А

 $\frac{6}{3}$

 \bigcirc



2	1	1		
DESCRIPTION		AUTH	DWG	СНК
See Sheet1		-	-	-