

- 3. ASSEMBLE DDS 1100D.
- 10. TWIST BATTERY CONNECTOR RED/BLACK WIRES TOGETHER.
- 11. PLACE 0.5" LENGTHS OF 3/32" HEATSHRINK OVER BATTERY CONNECTOR RED AND BLACK WIRES.
- 12. SOLDER RED/BLACK WIRES TO BATTERY CONNECTOR RED/BLACK WIRES.
- 13. LOCATE SHRINK TUBING OVER RED/BLACK SOLDER SPLICES AND SHRINK DOWN.

DF11 CONNECTOR	SBE P/N	COLOR	DIGIKEY CABLE P/N	DB9 CONNECTOR	9V BATT CONN	FUNCTION
PIN 1						
PIN 2	172099	BLACK	H3-BXG-10112-B4-ND	PIN 5		COMMON
PIN 3						
PIN 4						
PIN 5						
PIN 6	172462	YELLOW	H3-BXG-10112-Y4-ND	PIN 3		RX FROM PC
PIN 7						
PIN 8	172463	VIOLET	H3-BXG-10112-V4-ND	PIN 2		TX TO PC
PIN 9	172100	RED	H3-BXG-10112-R4-ND		RED	BATT+
PIN 10	172099	BLACK	H3-BXG-10112-B4-ND		BLACK	BATT-

TOLERANCES	SE	A-BIRI) E	LECT	RONIC	S, IN	[C]
FRACTIONAL	P/N	801583		SCALE	DRAWN BY	DLM/D)G
				APPROVED BY			
DECIMAL	TITLE	IMM PC	SERI	AL CABL	E WITH B	ATTERY	
ANGULAR	DATE	7/14/05	DWG N	10.	33049	REV	3