



## CDOM WETStar Characterization

Date: 07/14/2004

Customer: USGS

Job #: 0408018

S/N#: WSCD-1082P

Work order: 001

CDOM (Quinine Sulfate Dihydrate Equivalent) concentration expressed in ppb can be derived using the equation:

$$\text{CDOM (QSDE) (ppb)} = \text{Scale Factor} \times (\text{Output} - \text{Clean Water Offset})$$

	Analog meter	
Clean Water Offset (CWO)	0.059 V @	24 °C
Scale Factor (SF)	62 ppb/l/V @	24 °C
Maximum Output	5.1 V @	24 °C
Resolution	0.35 mV	
Ambient Characterization Temperature	24 ± 1 °C	
Current Draw	40 mA @ 12V (typical)	
12-hour Stability	0.38 mV/hr	
Temperature Stability, 25–2 °C	0.28 mV/°C	

### Definitions:

**CWO:** Clean Water Offset value obtained using pure filtered de-ionized water.

**SF:** Determined using the following equation:  $SF = x/(\text{output} - \text{CWO})$ , where x is the concentration of the solution used during the instrument characterization. SF is used to derive instrument output concentration from the raw signal output of the fluorometer.

**Maximum Output:** Maximum signal output of the fluorometer.

**Resolution:** Standard deviation of 1 minute of clean water data, sampled once per second.

**Ambient Characterization Temperature:** Room temperature at time of characterization.

**Current Draw:** The amount of current the instrument uses for operation.

**12-hour Stability:** Deviation of output averaged over 12 hours.

**Temperature Stability:** Measured output variation per degree.