Standard shipment shown below.



SBE 17plus



801380 data I/O cable (connection to computer serial port)



17132 CTD/SEARAM cable (connection to SBE 9*plus*)



17047 6-pin dummy plug & 17043 locking sleeve (2 of each)



17046 4-pin dummy plug & 17043 locking sleeve



50092 jackscrew kit



23155.1 spare magnetic switch plunger



50051 o-ring & hardware kit



60021 spare battery end cap o-ring & hardware kit



Hose clamps (3) in 50090 Mounting Kit





90504 NiMH battery charger, 801512 battery pack, 801509 battery charger cable, & 17015 AC power cable





20165 Spare fuses (2) for NiMH battery charger – stored in compartment inside charger



SEARAM user manual



Software, & electronic copies of software manuals & user manual