


Standard shipment shown below.



SBE 21



17725 grounding cable  
(from SBE 21)



90488 SEACAT/SEALOGGER  
RS-232 & Navigation  
Interface Box



17015 AC power cable  
for Interface Box



80438 cable  
(SBE 21 to Interface Box)



17031 pigtail  
with locking sleeve  
(SBE 21 to Interface Box)



801424 NMEA test cable  
(Interface Box to NMEA navigation  
device simulation computer)



171887 I/O Cable  
(Interface Box to computer)



50368 4-pin  
MS connector  
assembly  
(for SEACAT data  
I/O connector on  
Interface Box)




50369 5-pin  
MS connector  
assembly  
(for NMEA Input  
connector on  
Interface Box)



50092  
jackscrew kit



50091 cell cleaning  
solution  
(Triton X-100)



SBE 21  
user manual



Software, & electronic copies of  
software manuals & user manual