



SEA-BIRD ELECTRONICS, INC.

1808 136th Place N.E., Bellevue, Washington 98005 USA
Telephone: (425) 643-9866 Telex: 292915 SBEI UR
Fax: (425) 643-9954 email: seabird@seabird.com

SBE P/N 60043

DATE	REV	REVISION RECORD	AUTH	DR	CHK
7.22.05	A	Clarified battery replacement	CB	KLP	

SBE 39IM Standard Spares Kit

Kit Contents

SBE P/N	Part Description	Primary SBE Application	QTY
31274	O-ring, Parker 2-029 E603-70	Pressure/Temperature endcap o-rings	4
31332	O-ring, Parker 2-028 E515-80	IM endcap o-rings	4
60039	SBE39 Desiccant Packs, 1gm- 25 ea	Replace Desiccant bag every time you open the sensor	1 can

Procedure for SBE 39IM

A. REPLACING THE BATTERY

WARNING:

Due to the possible buildup of pressure in the sensor ALWAYS remove the coupler endcap first and DO NOT have it pointing toward yourself or any one else during removal.

1. Remove the two screws holding the endcap on.
2. Pull the endcap out slowly until you have enough room to reach in and disconnect the wire running from the endcap inside to the PCB.
3. Disconnect the wire from the PCB by removing the connector from the boardset.
4. Unscrew the sensor endcap.
5. Carefully pull the SBE39IM sensor assembly out of the housing.
6. Remove the 4-40 screw holding the Battery Holder to the boardset
7. Hold the battery connector plates with your thumb while replacing 9V battery.
8. Reinstall the Battery Holder to the boardset.
9. Carefully screw the sensor endcap back in.
10. Backfill the sensor with Argon or another Noble gas if available.
11. Reattach the connector from the coupler endcap to the PCB.
12. Install a new desiccant bag, and reseal the can.
13. Replace the coupler endcap and secure with screws.
 - a. Make sure there are no stray parts or wires caught by the endcap as you close the sensor.

B. REPLACING THE O-RINGS

1. Remove the old o-ring
 - a. Use a plastic spatula, or other NON-ABRASIVE, soft material to pry in underneath o-ring.
 - b. Pull back so o-ring stretches out of its groove, and cut it. Make sure not to scratch the o-ring seating surface.
 - c. Discard of old o-ring immediately to insure they do not get accidentally reused.
2. Installing the new o-Ring
 - a. Make sure o-ring is free of all dust and debris before applying any lubricant. Never clean with any abrasive material.
 - b. Lubricate o-ring with o-ring lubricant. This should be a silicone-based lubricant. Never use petroleum based lubricants on any SBE o-rings.

Sea-Bird Electronics Procedure

PROCEDURE NUMBER: 67163

TITLE: SBE PN 60043 SBE 39IM Standard Spares Kit

REVISION: A

EFFECTIVE DATE: 7/22/2005

CHECKED BY: _____ PAGE 1 of 1



SEA-BIRD ELECTRONICS, INC.

1808 136th Place N.E., Bellevue, Washington 98005 USA

Telephone: (425) 643-9866 Telex: 292915 SBEI UR

Fax: (425) 643-9954

email: seabird@seabird.com

- c. Slip o-ring over end cap and into the o-ring groove.
 - d. Always close and seal the sensor as soon as possible after replacing an o-ring.
 - e. Always clean and lubricate an o-ring before installing it.
3. Install a new desiccant bag, and reseal the can.

Sea-Bird Electronics Procedure

PROCEDURE NUMBER: **67163**

TITLE: **SBE PN 60043 SBE 39IM Standard Spares Kit**

REVISION: **A**

EFFECTIVE DATE: **7/22/2005**

CHECKED BY: _____ PAGE 1 of 1