

PO Box 518
620 Applegate St.
Philomath, OR 97370



(541) 929-5650
Fax (541) 929-5277
www.wetlabs.com

ECO CDOM Fluorometer Characterization Sheet

Date: 2/25/2016

S/N: BB2FLB-1408

CDOM concentration expressed in ppb can be derived using the equation:

$$\text{CDOM (ppb)} = \text{Scale Factor} * (\text{Output} - \text{Dark Counts})$$

Dark Counts	Digital 48 counts
Scale Factor (SF)	0.0906 ppb/count
Maximum Output	4130 counts
Resolution	1.0 counts
Ambient temperature during characterization	22.0 °C

Dark Counts: Signal output of the meter in clean water with black tape over detector.

SF: Determined using the following equation: $SF = x \div (\text{output} - \text{dark counts})$, where x is the concentration of the solution used during instrument characterization. SF is used to derive instrument output concentration from the raw signal output of the fluorometer.

Maximum Output: Maximum signal output the fluorometer is capable of.

Resolution: Standard deviation of 1 minute of collected data.